



Compact Bench Scale for Internal Use

B 100

Fault Codes Manual

5 Error Messages

message	description	possible cause
Err 4	Outside the zero setting range with respect to power on or using the Zero key.	The weight on the platform is out of the zero setting range. Wrong calibration. Cell failure. Electronics failure.
Err 5	Keyboard error.	Wrong action.
Err 6	A/D converter error.	Platform not installed. Cell failure. Electronics failure.

WorldWEIGH



Call your dealer for further support.
Quote the instrument model which is on the manual cover,
and the Serial Number (S/N) which is on the instrument label.

SOC. COOP. BILANCIAl CAMPOGALLIANO
41011 Campogalliano (MO) Via Ferrari, 16
tel. +39 (0)59 893 611 – fax +39 (0)59 527 079

servizio post-vendita
kundendienstservice

after sale service
servicio post-venta

service après-vente
serviço pòs-venda

tel. +39 (0)59 893 612 - fax +39 (0)59 527 294